



ULTRASONIC SPARK PLUG CLEANER 5L

REF: UC-9120L



Description

- One-key degassing can quickly remove air in water, and the ultrasonic cleaning effect is better
- Independently developed MCU-sweep ultrasonic generator drive, uniform and strong ultrasonic effect
- Independently developed industrial high Q value transducer with high ultrasonic conversion efficiency and long service life
- Power adjustment function, can meet different cleaning requirements
- Imported high strength glue, seedless nail bonding process, higher ultrasonic conversion efficiency
- Digital timing, cleaning time 10s-100min and digital heating control, temperature 20-80°C arbitrary setting
- The inner groove adopts imported SUS304, 1.0mm stainless steel stamping, ultrasonic exchange effect is better, longer service life
- The washing basket is made of high quality 304 stainless steel mesh welding, surface electrolytic polishing treatment
- The shell is made of high quality stainless steel, with better anticorrosion effect

ULTRASONIC SPARK PLUG CLEANER 5L

REF: UC-9120L

LCD display and control, simple operation



Safety switch, power interface



Portable drain valve



Foot pad, heat dissipation hole design



Stainless steel one-piece inner groove



Plastic handle

ULTRASONIC SPARK PLUG CLEANER 5L

REF: UC-9120L

Technical specifications

Parameters	Description
The tank size(L*W*H) mm	240*135*150
Dimensions(L*W*H) mm	304*165*292
Capacity(L)	5
Gross weight (KG)	5.4
Ultrasonic power (W)	120
Heating power(W)	200
Drain valve	Yes
Frequency(KHz)	39±1.5KHz
Time (Min)	10Sec~100Min
The heating temperature (°C)	20~80
Whashing basket	Included 1 Unit.